

LED 变焦摇头灯 EOS-550A			
模式 1	模式 2	模式 3	通道
1	1	1	Dimmer
2	2	2	Dimmer-16Bit
3	3	3	Shut
4	4	4	Red
		5	Red-16Bit
5	5	6	Green
		7	Green-16Bit
6	6	8	Blue
		9	Blue-Bit
7	7	10	White
		11	White-16Bit
8	8	12	Color Change
	9	13	CTC
9	10	14	Zoom
10	11	15	Pan
11	12	16	Pan-16Bit
12	13	17	Tilt
13	14	18	Tilt-16Bit
	15	19	P/T Speed
	16	20	Dimmer Mode
14	17	21	Control